

SAP ABAP table QDPS {Inspection stages for a dynamic modification rule}

QDPS-VERSTUFE = QDPS-PRSTUFE

QDPS-REDSTUFE = QDPS-PRSTUFE

1,1,0..N

QDPS
<u>MANDT</u> [CLNT (3)]
<u>DYNREGEL</u> [CHAR (3)]
<u>PRSTUFE</u> [NUMC (4)]
<u>PRSCHAERFE</u> [NUMC (3)]
<u>REDSTUFE</u> [NUMC (4)]
<u>VERSTUFE</u> [NUMC (4)]

QDPS-DYNREGEL = QDDR-DYNREGEL

1..N

QDDR
<u>MANDT</u> [CLNT (3)]
<u>DYNREGEL</u> [CHAR (3)]

1
{0,1}

QDPS-PRSCHAERFE = QDEP-PRSCHAERFE

0..N

QDPS-MANDT = T000-MANDT

QDEP
<u>MANDT</u> [CLNT (3)]
<u>PRSCHAERFE</u> [NUMC (3)]

0..N

T000
<u>MANDT</u> [CLNT (3)]